

BUCK ARTICULATOR™

Y STYLE HARNESS THAT ARTICULATES IN THREE PLACES



Meets the following requirements:
ASTM F887, ANSI Z359.11, CSA Z259.10-1

BuckArticulator™ 69B9D8G7H00

The BuckArticulator™ is a Y Style harness that articulates in three places, making it ideal for anything that requires the user to bend, reach, twist, and climb at heights—perfect for fall arrest, work positioning and rescue.

This harness can be used by itself or the user can easily attach to a lineman's body belt. The harness floats freely through the waist straps while

the body belt stays in position to allow for lifting arms without restriction.

The BuckArticulator™ has three 5000lb rated d-rings in the front of the harness, two at the sternum (better for rescue), one at the abdomen, and a 5000lb rated nylon loop dorsal attachment that can be used for fall arrest or rescue. Leg straps are color coded using 4000lb rated, quick

connect buckles to make donning quick and easy.

The BuckArticulator™ was developed while working with Fortis in Alberta, Canada. Buckingham listened to concerns and worked together to develop a harness ideal for anyone who has to eliminate restriction found in traditional harnesses.



Waist Belt on **20192M** fastened behind the harness to eliminate restriction of user lifting arms.



Ideal Body Belt **20192M** to be Used with the BuckArticulator™



HOW TO ATTACH BELT:



- ① Disconnect interlock buckle on back of harness.
- ② Weave the web and buckle through the rectangle buckle.
- ③ Place body belt on user.
- ④ Pass buckle and web through body belt between outer tool loop strap and above the floating d-ring strap.
- ⑤ Weave short strap w/female buckle between tool loop strap on belt and above the floating d-ring strap and reconnect female and male buckles together.