

ADJUSTABLE BODY BELT

A STEP - BY - STEP GUIDE

Adjustable Belt Strap



Adjustment Instructions

To Lengthen the Adjustable Belt Strap

1. Lay the belt on a flat surface with the belt strap facing up.



2. Rotate the adjustment buckle 90° so that it is perpendicular to the strap.

3. Feed extra webbing from top of strap through the adjustment buckle forming a

4. Once adjusted, lay the buckle flat against the strap and pull excess strap towards the billet end of the belt, flattening the strap.

slack loop. Pull webbing slack loop from the bottom, away from the buckle, lengthening the strap to the desired length.

To Shorten the Adjustable Belt Strap

1. Lay the belt on a flat surface with the belt strap facing up.

2. Rotate the adjustment buckle 90° so that it is perpendicular to the strap.

3. Create slack in the belt strap by pulling the billet side of the strap towards the adjustment buckle.

4. Feed extra webbing from top of strap through the adjustment buckle forming a slack loop. Pull webbing slack loop from the



bottom, away from the buckle, lengthening the strap to the desired length.

5. Once adjusted, lay the buckle flat against the strap and pull excess strap towards the billet end of the belt, flattening the strap.



Adjustable Dee Piece Adjustment Instructions

To Lengthen the Adjustable Dee Piece

1. Lay the belt on its edge with the lower



Dee piece facing up and away.

2. Rotate the adjustment buckle 90° so it is perpendicular to the dee piece strap.

4. Once adjusted, lay the buckle flat against the strap and pull the two work positioning D-rings away from each other, tightening and flattening the Dee piece.

3. Feed extra webbing from top of strap



through the adjustment buckle forming a slack loop. Pull webbing slack loop from the

bottom, away from the buckle,



lengthening the Dee piece to the desired length.

To Shorten the Adjustable Dee Piece



1. Lay the belt on its edge with the lower Dee piece facing up and away.

2. Rotate the adjustment buckle 90° so it is perpendicular to the dee piece strap.

3. Create slack in the Dee piece by pushing the two work positioning D-ring towards each other.

5. Once adjusted, lay the buckle flat against the strap and pull the two work positioning D-rings away from each other, tightening and flattening the Dee piece.

4. Feed extra webbing from top of strap through the adjustment buckle forming a slack loop. Pull

webbing slack loop from the bottom, away from the buckle, lengthening the Dee piece to the desired length.

